

For Kaypro 2,4 (1983): More Function Keys

The following function keys have are now implemented for your keyboard. This gives you 90+ instead of 10 function keys! This page replaces Pages 23-24 of the MS-DOS Guide.

IBM KEYSTROKE		LOUIVALENT KAYPRO KEYSTROKE	
		FIRST	SECOND (IF NEEDED)
F1	keypad 1	keypad 1	
F2	keypad 2	keypad 2	
F3	keypad 3	keypad 3	(from DOS repeats last command line)
F4	keypad 4	keypad 4	
F5	keypad 5	keypad 5	
F6	keypad 6	keypad 6	
F7	keypad 7	keypad 7	
F8	keypad 8	keypad 8	
F9	keypad 9	keypad 9	
F10	keypad 0	keypad 0	
Page Up	keypad -	keypad -	
Page Down	keypad ,	keypad ,	
Home	keypad .	keypad .	
END	keypad ENTER	keypad ENTER	
INS	keypad ENTER	keypad ENTER	
DEL	keypad ENTER	keypad ENTER	
CTRL	keypad ENTER	keypad ENTER	
CTRL	keypad ENTER	keypad ENTER	
CTRL END	keypad ENTER	keypad ENTER	
CTRL Page Down	keypad ENTER	keypad ENTER	
CTRL Home	keypad ENTER	keypad ENTER	
CTRL Page Up	keypad ENTER	keypad ENTER	
F11 (uppercase F1)	keypad ENTER	keypad 1	
F12 (uppercase F2)	keypad ENTER	keypad 2	
F13 (uppercase F3)	keypad ENTER	keypad 3	
F14 (uppercase F4)	keypad ENTER	keypad 4	
F15 (uppercase F5)	keypad ENTER	keypad 5	
F16 (uppercase F6)	keypad ENTER	keypad 6	
F17 (uppercase F7)	keypad ENTER	keypad 7	
F18 (uppercase F8)	keypad ENTER	keypad 8	
F19 (uppercase F9)	keypad ENTER	keypad 9	
F20 (uppercase F10)	keypad ENTER	keypad 0	
F21 (CTRL F1)	keypad ENTER	SHIFT 1	
F22 (CTRL F2)	keypad ENTER	SHIFT 2	
F23 (CTRL F3)	keypad ENTER	SHIFT 3	
F24 (CTRL F4)	keypad ENTER	SHIFT 4	
F25 (CTRL F5)	keypad ENTER	SHIFT 5	
F26 (CTRL F6)	keypad ENTER	SHIFT 6	
F27 (CTRL F7)	keypad ENTER	SHIFT 7	
F28 (CTRL F8)	keypad ENTER	SHIFT 8	
F29 (CTRL F9)	keypad ENTER	SHIFT 9	
F30 (CTRL F10)	keypad ENTER	SHIFT 0	
F31 (ALT F1)	keypad ENTER	q	
F32 (ALT F2)	keypad ENTER	w	
F33 (ALT F3)	keypad ENTER	e	
F34 (ALT F4)	keypad ENTER	r	
F35 (ALT F5)	keypad ENTER	t	
F36 (ALT F6)	keypad ENTER	y	

IBM KEYSTROKE		LOUIVALENT KAYPRO KEYSTROKE	
		FIRST	SECOND (IF NEEDED)
F37 (ALT F7)	keypad ENTER	u	
F38 (ALT F8)	keypad ENTER	i	
F39 (ALT F9)	keypad ENTER	o	
F40 (ALT F10)	keypad ENTER	p	
ALT A	keypad ENTER	A	
ALT B	keypad ENTER	B	
ALT C	keypad ENTER	C	
ALT D	keypad ENTER	D	
ALT E	keypad ENTER	E	
ALT F	keypad ENTER	F	
ALT G	keypad ENTER	G	
ALT H	keypad ENTER	H	
ALT I	keypad ENTER	I	
ALT J	keypad ENTER	J	
ALT K	keypad ENTER	K	
ALT L	keypad ENTER	L	
ALT M	keypad ENTER	M	
ALT N	keypad ENTER	N	
ALT O	keypad ENTER	O	
ALT P	keypad ENTER	P	
ALT Q	keypad ENTER	Q	
ALT R	keypad ENTER	R	
ALT S	keypad ENTER	S	
ALT T	keypad ENTER	T	
ALT U	keypad ENTER	U	
ALT V	keypad ENTER	V	
ALT W	keypad ENTER	W	
ALT X	keypad ENTER	X	
ALT Y	keypad ENTER	Y	
ALT Z	keypad ENTER	Z	
ALT 1	keypad ENTER	1	
ALT 2	keypad ENTER	2	
ALT 3	keypad ENTER	3	
ALT 4	keypad ENTER	4	
ALT 5	keypad ENTER	5	
ALT 6	keypad ENTER	6	
ALT 7	keypad ENTER	7	
ALT 8	keypad ENTER	8	
ALT 9	keypad ENTER	9	
ALT 0	keypad ENTER	0	
ALT -	keypad ENTER	-	
ALT =	keypad ENTER	=	

When using the chart be sure to enter the keystrokes exactly as shown. If the chart says 'keypad' the key must be entered from the numeric keypad. Otherwise, the stroke must be entered from the main pad.

CTRL 3 (from the main pad) is a toggle that turns the above function keys on and off. When the keys are turned 'off' they will have their normal function. When CTRL 3 is entered, the computer will 'beep' to let you know the toggle has been accepted.

